

Surface preparation and conditioning

AUGUST 2017 SUN MON TUE WED THU FRI SAT 31 1 *2 3 4 5 0 17 8 9 10 11 12 19 Concrete curing in progress till 29-08-17 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 1 2 3

Ensure sufficient concrete curing



Check substrate surface and level



Remove surface protrusion or debris



Clean surface

2) Laying screed / render



Ensure surface saturated-dry



Lay screed / render



Damp cure screed



Check for hollowness

3) Preparation and application of adhesive



Mark gridlines



Follow manufacturers' instructions



Mix adhesive



Do not use beyond pot life



Spread and trowel adhesive in straight line

4) Laying of tiles



Clean back face of tile



Tap tile into position



Check alignment and level



Allow tiles to set



5) Grouting

Fill joints with grout



Clean excessive grout



6) Protection

Lay protection sheet



Restrict access to completed works